

JGS500/600 BOV instructions

PORTS-



Springs-



(S)mall (M)edium (L)arge

Vacuum ratings on spring combinations (in/hg)

(The amount of vac. That can be applied before the valve begins to open)

Small 5.5"

Medium 9.5"

Large 16.5"

Lg + Sm 21"

Lg + Md 26"